

RCA M21500 USER MANUAL



Table of Contents

- [important information](#)
- [Note To Cable TV Installer](#)
- [Table of Contents](#)
- [basic tour of the remote](#)
- [Component Buttons](#)
- [Menu Buttons](#)
- [menu basics](#)
- [Moving through the Menus](#)
- [Using Your TV and Remote](#)
- [vcr codes](#)
- [Record one TV program and watch another](#)
- [Adjusting Your TV](#)
- [Picture Settings](#)
- [Sound Settings](#)
- [using advanced features](#)
- [Adding and Deleting Channels in Memory](#)
- [Naming the Channels](#)
- [Setting the Sleep Timer](#)
- [Cancel the Timer](#)
- [Setting the Alarm Clock](#)
- [Selecting a Language](#)
- [Watching Closed Captioning](#)
- [Setting Your TV for Antenna or Cable](#)
- [Displays on the Screen](#)
- [Trouble Checks](#)
- [Checks And Adjustments](#)
- [cleaning your tv](#)
- [Index](#)
- [Other ManualsLib Projects](#)

M21500
M27500

USER'S GUIDE

Important Information .i

Table of Contents 1

Quick Guide to Your TV2-5

Using Your Remote 6-15


Adjusting Your TV16-19

Using Advanced Features 20-

27

References 28-33

IT IS IMPORTANT TO READ THIS
MANUAL BEFORE OPERATING THIS
UNIT FOR THE FIRST TIME.



50 SERIES

COLOR TV

Important Information

WARNING

To reduce the risk of fire or shock hazard, do not expose this TV to rain or moisture.

WARNING

RISK OF ELECTRIC SHOCK
DO NOT OPEN


TO REDUCE THE RISK OF ELECTRIC SHOCK, DO NOT REMOVE COVER (OR BACK). NO USER SERVICEABLE PARTS INSIDE. REFER SERVICING TO QUALIFIED SERVICE PERSONNEL.



This symbol indicates “dangerous voltage” inside the product that presents a risk of electric shock or personal injury.



This symbol indicates important instructions accompanying the product.



To prevent electric shock, match wide blade of plug to wide slot, fully insert.

Cautions

Do not defeat the safety feature of the plug. The wide blade fits into the wall socket only one way. If you need an extension cord, make sure it matches the plug of the TV.

For U.S.A.: Operate TV only on 120 volts, 60 Hz AC power (normal house power).

For Mexico: Operate TV only on 127 volts, 60 Hz AC power (normal house power). Average Maximum Power Consumption is 100 watts.

For safety reasons, make sure any equipment or accessories connected to this product bears the UL listing mark or the CSA certification mark. If in doubt, contact qualified service personnel.

FCC Regulations state that unauthorized changes or modifications to this equipment may void the user's authority to operate it.

Note To Cable TV Installer

This reminder is provided to call your attention to Article 820-40 of the National Electrical Code (Section 54 of the Canadian Electrical Code, Part 1) which provides guidelines for proper grounding and, in particular, specifies that the cable ground shall be connected to the grounding system of the building as close to the point of cable entry as practical.

Table of Contents

Important Information	Warning _____	i
Quick Guide to Your TV	Startup _____	2-3
	Hook up, Plug in TV, Put Batteries in the Remote, Turn on the TV, Place Channels into Memory, Set the Time	
	Basic Tour of the Remote _____	4
	Basic Button Layout and Functions	
	Menu Basics _____	5
	Colors, Menu Buttons, Moving through the Menus	
Using Your TV and Remote	With Remote Buttons _____	6-7
	With VCRs _____	8-11
	With a Cable Box _____	12-13
	With a Laserdisc Player _____	14
	With Audio Equipment _____	15
Adjusting Your TV	Overall Picture _____	16
	Picture Settings _____	17
	Color, Tint, Brightness, Sharpness, Autocolor, Picture Reset	
	Sound Settings _____	18-19
	Stereo, Expanded Stereo, SAP, Tone, Speakers	
Using Advanced Features	Placing Channels in Memory / Autoprogram _____	20
	Adding and Deleting Channels in Memory _____	21
	Naming the Channels _____	22
	Setting the Sleep Timer _____	23
	Setting the Alarm Clock _____	24
	Selecting a Language _____	25
	Watching Closed Captioning _____	26
	Setting Your TV for Antenna or Cable _____	27
References	Front Panel Buttons _____	28
	Displays on the Screen _____	29
	Trouble Checks _____	30-31
	Cleaning _____	31
	Index _____	32-33


Quick Guide to Your TV

Startup

The steps below will get your TV connected and ready for watching.
For more details, see the page numbers listed.


1. Hook up your TV

Details are in the Connections Guide.




Hook up any antennas, cables or other equipment to your TV before you follow the steps below.

2. Plug in the TV



Plug the cord into the outlet, matching the wide and the small end of the plug with the outlet.

3. Put Batteries in the Remote



- A. Pull off the cover of the battery compartment.
- B. Place the four AAA batteries as shown, matching the **+** and **-** end of each battery in the compartment.
- C. Replace the cover.

Quick Guide to Your TV


Startup

4. Turn on the TV



Press TV on the remote.


OR



Press POWER on the TV.


5. Place all available channels in memory (AutoProgram)

Details for adding and deleting channels are on page 21.



- Press MENU•PROG until the Setup menu is selected. This menu is white.
- Press MOVE H to highlight Autoprogram.
- Press MOVE E to start placing channels in the TV's memory.
- Wait until TV has cycled through all the channels and returns to original channel.

6. Set the Time



- Press MENU•PROG until the Alarm menu is selected. This menu is green.
- The Clock is automatically highlighted the first time you set it. If it is not, press MOVE H (down) to highlight it.
- Press MOVE F to set the hour.
- Press MOVE E to set the minutes.

Quick Guide to Your TV

Basic Tour of the Remote

Basic information about your remote is shown below. This will give you a general idea of how your remote works. *For more details, see pages 6–15.*

TV Power Button

Turns the TV on.

Sets the remote to control the TV.

Volume and Channel Controls

Details are on page 6.

Operates TV when remote is set to control the TV.

Operates the TV and advanced features.



Component Buttons

Details are on pages 8–15.

Controls components such as a VCR, laserdisc player, audio equipment, and a cable box.

Menu Buttons

See next page for details.

Changes the menus and features on the screen.




Quick Guide to Your TV

Menu Basics

General information about using the on-screen menu system is shown below. *Details on using the remote buttons are on pages 6-7. Many menu items are explained in detail in Using the Advanced Features starting on page 20.*

Colors




Press MENU•PROG repeatedly to see each of the four menu colors.


Each menu has a different color background as shown at the left.

Menu Buttons

These buttons are used with the TV's menus to adjust the features. You can use the menu buttons on the remote or the front of the TV.



Moving through the Menus



1. Press MENU•PROG on the remote or MENU on the front panel to move from menu to menu.
2. Press MOVE 4/3 on the remote or CHANNEL up / down on the front panel to move up and down through the features in the menu.
3. Press MOVE F and E on the remote or VOLUME +/- on the front panel to move left and right on the menu lines.

Using Your TV and Remote

With Remote Buttons



POWER

Turns off the TV.

Turns off compatible VCRs.

Turns on a component after a component button is pressed.

AUDIO, VCR, VCR2•LD, DSS•CABLE, TV

Sets the remote to control the component. VCR2•LD can only be programmed for one component: either a VCR or a Laserdisc Player.

See Using the Remote with a VCR, Cable Box, Laserdisc Player and Audio equipment on pages 8–15.

TV

Turns on the TV.

Shows the displays on the screen.

Sets the remote to control the TV.

See Using the Remote with a VCR, Cable Box, Laserdisc Player and Audio equipment on pages 8–15.

REW (Rewind)

Rewinds a tape or laserdisc.

Searches backward while tape or laserdisc is playing.

PLAY

Plays tape or laserdisc.

FF (Fast Forward)

Fast forwards a tape or laserdisc.

Searches forward while tape or laserdisc is playing.

REC (Record)

Starts recording onto tape.

STOP

Stops tape or laserdisc.

PAUSE

Pauses tape or laserdisc.

DISPLAY

Shows displays on the screen.

Clears menus from the screen.

SKIP (Commercial Skip)

Allows you to scan other channels during commercials.

Each press adds 30 seconds. TV switches back to original channel when time runs out. Press CLEAR to cancel SKIP.

CHAN 2 and 1

(Channel up and down)

Scans up and down through channels in the TV's memory.

Moves through channels in VCR's memory.

VOL + and -

(Volume up and down)

Raises and lowers sound.

MUTE

Switches the TV sound on or off.

PREV CH (Previous Channel)

Changes back and forth between two channels.

Select a channel and then select another. Press PREV CH to switch between the two channels.

Using Your TV and Remote

With Remote Buttons



Number Buttons (0-9)

Selects any channel number.

Two numbers must be pressed for each channel. Press 0 and 6 for channel 6. For three digit channels, press and hold 1 until 1-- appears on the screen. Then press the other two numbers.

INPUT

Switches between the TV channels and Video 00.

ANT A•B (Antenna)

Used as TV / VCR button when remote is set to control the VCR.

CLEAR

Clears menus and displays from the screen.

Clears items from VCR timer programs and VCR's clock.

MENU•PROG (Program)

Shows menus on the screen and moves from menu to menu.

Sets VCR clock and programs timer on VCR.

RESET

Returns the picture adjustments to the original settings.

MOVE F and E (left and right)

Moves left and right on a menu line. *See Menu Basics on page 5.*

Changes a feature setting.

MOVE G and H (up and down)

Moves up and down menus. *See Menu Basics on page 5.*

Using Your TV and Remote

With VCRs: Programming the Remote

Refer to the Connection Book or the VCR's owners manual to hook up your VCRs. The remote may need to be programmed for your VCR. This remote may not operate all models of brands listed below. Use the codes below or on the sheet packed in with your remote.

1. Test the remote

2. Program the remote for your VCRs



- A. Press VCR or VCR2 to turn the VCR on.
- B. Press the VCR buttons shown at the left. If your VCR does not work, program VCR or VCR2 with a VCR code from the list below.
- A. Point the remote at the VCR and hold VCR.
- B. Enter the code for your brand from the code list below.
- C. Release VCR.
- D. Press POWER. If nothing happens, try pressing VCR and then POWER.
- E. Repeat A–D with another code if the first one does not work or if a second VCR is connected.

VCR Codes

Aiwa 15	Lloyd 15	Sanyo.....02,12
Akai 03,22,23	Magnavox 08,29	Scott.....04,13,41
Audio Dynamics.....14,16	Marantz 02,08,14,16,29,30	Sears 02,05,09,12,18,19,35,43
Broksonic 10	Marta 09	Sharp 06,24,39
Canon 08	MEI 08	Shintom 17,26,31
Capehart.....01	Memorex 08,09,12,15	Sony.....17,26,38
Citizen 09	MGA 04,27	Sylvania 08,15,29
Craig 07,12	Minolta 05,35	Symphonic 02,15
Curtis Mathes.....00,08,15	Mitsubishi 04,05,27,35,40	Tashiko 09
Daewoo 13	Montgomery Ward.....06	Tatung.....30
dbx 14,16	MTC 07,15	Teac 15,30
Dimensia 00	Multitech 07,15,31,32	Technics 08
Dynatech 15	NEC 02,14,16,30	Teknika 08,09,15,21
Emerson ...09,10,13,15,20,23,24,34,41	Panasonic 08	Toshiba 05,13,19
Fisher 02,12,18,19,43	Pentax 05,35	Totevision 07,09
Funai.....15	Philco 08,29	Unitech 07
GE 00,07,08,32,37	Philips.....08,29	Vector Research 14,16
Goldstar.....09,14	Pioneer 05,16,33	Victor 16
Harman Kardon.....14	ProScan.....00	Video Concepts 14,16
Hitachi 05,15,35,36	Quartz.....02	Videosonic.....07
Instant Replay 08	Quasar 08	Wards.....
JCL 08	RCA 00,05,07,08,28,35,37	05,06,07,08,12,13,15,25,31,35
JCPenney.....02,05,07,08,14,16,30,35	Realistic.....02,06,08,09,12,15,19,43	Yamaha.....02,14,16,30
JVC 02,14,16,30	Samsung.....07,13,22,32,42	Zenith.....11,17
Kenwood.....02,14,16,30	Sansui 16	

Using Your TV and Remote

With VCRs: Setting the VCR1 Channel


The VCR 1 Channel works with VCR on the remote. If the VCR 1 Channel is set, pressing VCR selects the channel to see the VCR picture. The VCR 1 Channel setting depends on which diagram you have used from the Connection Guide. If you want to turn this feature off, set the VCR 1 Channel to Disable. *Refer to the chart below for your setting.*

1. Select the Setup Menu




- A. Press TV to set the remote to control the TV.
- B. Press MENU•PROG to select the Setup menu. This menu is white.

2. Highlight VCR1 Channel



- A. Press MOVE H (down) to highlight the VCR 1 Channel.
- B. Press **E** to highlight the channel.

3. Enter channel number



- A. Enter channel 00, 03, or 04. Choose your setting from the chart below. Press MOVE H (down) until “Disabled” is displayed to turn the feature off.

Diagram used from the Connection Guide:	Set VCR1 Channel to:
1B, 1C, 2B, 2C, 3B, 3C, 4C, 5C	00
4B, 5B	3 or 4 (same as 3/4 switch)

Using Your TV and Remote

With VCRs: Basic Operation

If the remote operates your VCR, this page and the next will show you how to use it for basic functions. *See page 7 for more details on buttons used with your VCR.*

Turn on the VCR

Turn off the VCR



- A. Press channel 00 on the TV to see what the VCR is doing.
- B. Press VCR or VCR2 to set the remote to control the VCR.
- C. Press POWER to turn on the VCR if it did not turn on when you pressed VCR or VCR2.

- A. Press VCR or VCR2 to set the remote to control the VCR.
- B. Press POWER.

Using Your TV and Remote

With VCRs: Basic Operation

If the remote operates your VCR, this page and page 10 will show you how to use it for basic functions. *See page 7 for more details on buttons used with your VCR.*

Record one TV program and watch another



- Press VCR or VCR2 to set the remote to control the VCR.
- Tune the VCR to the channel you want to record using CHANNEL up and down or pressing two number buttons.
- Press RECORD to start recording.
- Press TV/VCR on the VCR.
- Press TV to set the remote to control the TV.
- Press CHANNEL up or down to change channels on the TV.
- To see the channel you are recording, tune the TV back to channel 00.

Watch a tape in your VCR

- Turn on VCR.
- Insert a tape in the VCR.
- Press PLAY to start the tape playing.
- Press STOP when you are finished.
- Press REW to rewind the tape.

Using Your TV and Remote

With a Cable Box: Programming and Basic Operation

Refer to the *Connection Book* or contact your cable company to hook up your cable box. If you have a cable box with its own remote, then you may also be able to use the TV's remote with your cable box. This remote may not operate all models of brands listed below. Use the codes below or on the sheet packed in with your remote.

Program the remote for your cable box



- A. Point the remote at the cable box and hold CABLE.
- B. Enter the code numbers for your brand from the list below.
- C. Release CABLE.
- D. Press POWER to turn it on. If nothing happens, try pressing CABLE and then POWER.
- E. Repeat A-D with another code if the first one does not work.

Basic Operation:

Turn on the Cable Box

- A. Tune TV to channel 02, 03, 04, 05, or 06--the cable box channel.
- B. Point remote at the cable box and press CABLE.
- C. Press POWER to turn it on.
- D. Press CHANNEL up or down to change channels on the cable box.

Turn off the Cable Box

- A. Press CABLE.
- B. Press POWER to turn it off.

Cable Box Codes

ABC 22,46	NSC 09	Sprucer.....27
Anvision.....07,08	Oak 01,16,38	Starcom 46
Cablestar 07,08	Oak Sigma 16	Sylvania.....11
Eagle 08	Panasonic.....03,27,39	Teknika 06
Eastern International.....02	Philips 07,08,19,21,26,28,29,32,33,40,41	Texscan.....10,11
General Instrument 04,05,15,23,24,25,30,36,46	Pioneer 18,20,44	Tocom.....17,21,49,50
Hamlin 12,13,34,48	Randtek.....07,08	Unika.....31,32,41
Hitachi.....37,43,46	RCA 00,27	Viewstar 07,08,19,21,26,28,29,32,33,40,41
Jerrold.....04,05,15,23,24,25,30,36,45,46,47	Regal.....12,13	Warner Amex.....44
MACOM 37,43	Regency.....02,33	Zenith 14,42
Magnavox.....07,08,19,21,26,28,29,32,33,40,41	Samsung 44	
	Scientific Atlanta.....03,22,35	
	Signature.....46	

Using Your TV and Remote

With a Cable Box: Setting the Cable Channel


The Cable Channel works with CABLE on the remote. If the Cable Channel is set, pressing CABLE selects the channel to see cable channels. The Cable Channel setting depends on which channel your cable box must be on to see cable channels. The channels usually used are 02, 03, 04, 05 or 06. *Consult your cable company for more information.*

1. Select the Setup menu



- A. Press TV to set the remote to control the TV.
- B. Press MENU•PROG to select the Setup menu. This menu is white.

2. Highlight Cable Channel



- A. Press MOVE H (down) to move down the menu until Cable Channel is highlighted.
- B. Press E to underline the channel.

3. Enter channel number



- A. Enter the number for your cable box, either 02,03,04,05, or 06. Press MOVE H (down) until "Disabled" is displayed to turn this feature off.

Using Your TV and Remote

With a Laserdisc Player: Programming and Basic Operation

Refer to your Laserdisc Player owner's manual to hook up your Laserdisc Player.

The remote may need to be programmed for your laserdisc player. This remote may not operate all models of brands listed below. Use the codes below or on the sheet packed in with your remote.

Program the remote for your Laserdisc Player

Basic Operation

Laserdisc Player Codes

Pioneer	33
ProScan	33
RCA	33



- Point the remote at the laserdisc player and hold LD.
- Enter the code for your brand from the code list below.
- Release LD.
- Press POWER. If nothing happens, try pressing LD and then POWER.

- Tune TV to channel 00, 03, or 04.
- Point the remote at the laserdisc player and press LD.
- Press POWER to turn it on.
- Use the buttons on the remote that relate to laserdisc player functions. Not all buttons highlighted may work with your laserdisc player.
- Press POWER to turn it off.

Using Your TV and Remote

With Audio Equipment: Programming and Basic Operation

Refer to the Connection Book or your Audio equipment owner's manual to hook up your audio equipment. Your remote controls only RCA audio equipment such as a radio, CD player, tape player, turntable, or amplifier. The remote may need to be programmed for your equipment. This remote may not operate all models of brands listed below. Use the codes below or on the sheet packed in with your remote.

Program the remote for audio equipment

Basic Operation

Audio Codes

RCA / Dimensia	
AM / FM.....	03
CD	07
Tape	06
Phono	05
Aux	04



- Point the remote at the audio equipment and hold AUDIO.
- Enter the code from the code list.
- Release AUDIO.
- Press POWER to turn it on. If nothing happens, try pressing AUDIO and then POWER.
- Repeat A–D with another code if the first one does not work.


- Point the remote at the audio equipment and press AUDIO.
- Press POWER to turn it on.
- Use the buttons on the remote that relate to audio functions. Not all buttons highlighted may work with your equipment.
- Turn the audio equipment off using the audio component's power off button.

Adjusting Your TV

Overall Picture


Follow the steps below to lighten or darken the overall picture without changing the color levels.

1. Select the Controls Menu




Press MENU•PROG to select the Controls menu. This menu is yellow.

2. Highlight Picture



Press MOVE H (down) to highlight Picture.

3. Use MOVE E and F to adjust the Picture



Press MOVE E (right) to lighten the picture.

OR


Press MOVE F (left) to darken the picture.

Adjusting Your TV

Picture Settings

Follow the steps below to change the picture on the screen to your personal setting. The chart at the bottom of the page explains your options.

1. Select the Adjust Menu




Press MENU•PROG repeatedly to select the Adjust menu. This menu is light blue.

2. Highlight item to change

Press MOVE H (down) to highlight the picture item you want to adjust.

3. Use MOVE E or F to adjust each item



Press MOVE E or F to adjust each item.


	Press MOVE E to:	Press MOVE F to:
Color	Increase color richness	Lower color to black and white
Tint	Give red tint to skin color	Give green tint to skin color
Bright (Brightness)	Add more light to dark parts of the picture	Add more dark to light parts of the picture
Sharp (Sharpness)	Show cleaner, clearer images	Make picture more smooth
Autocolor	Turn on to keep Color and Tint in proper balance each time you change channels	Turn off for manual adjustment of Color and Tint
Picture Reset	Reset the picture back to the original settings	Reset the picture back to the original settings

Adjusting Your TV

Sound Settings: Stereo, Expanded Stereo, SAP and Tone

Follow these steps to adjust the Stereo, Expanded Stereo, SAP or Tone of your TV. SAP (Second Audio Program) is sometimes used to offer the program being watched in another language. The chart below explains your options.

1. Select the Controls Menu




Press MENU•PROG to select the Controls menu. This menu is yellow.

2. Highlight item to change

Press MOVE H (down) to highlight the sound item you want to adjust.

3. Use MOVE E or F to adjust each item



Press MOVE E or F to adjust each item.

Stereo	On Sound is automatically reproduced in stereo or mono, whichever the TV station is broadcasting.	Off Sound is reproduced in mono.	Expanded Expanded stereo adds greater width and dimension to stereo broadcasts creating a more spacious stereo sound effect.
SAP	On Sound is reproduced in another sound channel. If nothing happens, your broadcast may not have SAP.	Off Sound is reproduced in Stereo, Expanded Stereo or Mono, whichever is selected in the Stereo Menu Item.	
Tone	High High pitched sounds are louder.	Low Low pitched sounds are louder.	

Adjusting Your TV

Sound Settings: Speakers

Follow the steps below to turn the speakers on or off in your TV. The chart below explains your options.

1. Select the Setup Menu

Controls	Alarm	Adjust	Setup
English	Français	Español	
Autoprogram			
Label	13		Clear
Channel Memory: 13 Stored			
Cable/Air: Cable			
VCR 1 Channel: Video			
Cable Channel: 03			
Speakers: Off			

Press MENU•PROG repeatedly to select the Setup menu. This menu is white.

2. Highlight speakers

Controls	Alarm	Adjust	Setup
English	Français	Español	
Autoprogram			
Label	13		Clear
Channel Memory: 13 Stored			
Cable/Air: Cable			
VCR 1 Channel: Video			
Cable Channel: 03			
Speakers: Off			

Press MOVE H (down) until Speakers is highlighted.

3. Turn Speakers on or off

Controls	Alarm	Adjust	Setup
English	Français	Español	
Autoprogram			
Label	13		Clear
Channel Memory: 13 Stored			
Cable/Air: Cable			
VCR 1 Channel: Video			
Cable Channel: 03			
Speakers: On			

Press MOVE E or F to turn the speakers on or off.

Speakers	On	Off
	The sound comes from the TV's internal speakers.	No sound comes from the TV.

Using Advanced Features

Placing Channels in Memory (Autoprogramming)

Only channels 2–13 appear in the TV's memory when you first turn it on. The channels available in your area must be programmed into the TV's memory when you hook up your TV. Using CHANNEL up or down allows you to scan through these channels.

You may want to add or delete a few channels if some stations have weak signals or were off the air when the TV was programmed. *Refer to the Add or Delete Channels section on the next page.*

Place channels in memory (AutoProgram)




- A. Hook up an antenna, cable or components before you begin these steps or you will not be able to add channels into memory.
- B. Press MENU•PROG repeatedly to select the Setup Menu and highlight Autoprogram. This menu is white.
- C. Press MOVE H (down) to start the TV adding all active channels into memory.
- D. Wait until the TV has cycled through all the channels and returns to the original channel.

Using Advanced Features

Adding and Deleting Channels in Memory

You may want to add or delete a few channels if some stations have weak signals or were off the air when the TV was programmed. *Refer to the Add or Delete Channels section below.*

Adding and deleting channels in memory



- A. Press MENU•PROG repeatedly to select the Setup menu. This menu is white.
- B. Press MOVE H (down) to highlight Channel Memory.
- C. Press MOVE E to underline the channel number.
- D. Select the channel number you want to add or delete with the number buttons.
- E. Press MOVE E to add or delete a channel (you will see Stored on the screen when added and Erased when deleted).
- F. Repeat D and E for more channels.

Using Advanced Features

Naming the Channels

You can name the channels using the character list below. **Full** appears beside Label when the memory is used up. **Fixed** appears beside Label for channel 00—it cannot be named.

1. Name a channel

				12
Controls	Alarm	Adjust	Setup	
English	Français	Español	Autoprogram	
Label	12		Clear	
Channel Memory: 12 Stored				
Cable/Air: Cable				

				XET 12
Controls	Alarm	Adjust	Setup	
English	Français	Español	Autoprogram	
Label	12	XET_	Clear	
Channel Memory: 13 Stored				
Cable/Air: Cable				

- Press MENU•PROG repeatedly to select the Setup menu. This menu is white.
- Press MOVE H (down) to highlight Label.
- Press MOVE E to underline the channel number.
- Select the channel number with the number buttons.
- Press MOVE E to underline the first character of the name.
- Choose the character using MOVE G/H (up or down).
- Repeat E–F to complete the name.
- Press MOVE F to move back-ward if you want to change an item.

2. Erase a name

				12
Controls	Alarm	Adjust	Setup	
English	Français	Español	Autoprogram	
Label	12		Clear	
Channel Memory: 13 Stored				
Cable/Air: Cable				

- Follow A and B above.
- Press MOVE E until clear is underlined.
- Press MOVE G/H (up or down) to clear the name.

Character List


A B C D E F G H I J K L M N O P Q R S T U V W X Y Z &
' () á + , - . / 0 1 2 3 4 5 6 7 8 9 : ; < = > ? @ blank space

Using Advanced Features


Setting the Sleep Timer

You can set your TV to turn itself off. If you're watching TV at night and fall asleep, the TV will turn off for you.


1. Set Sleep Timer



- A. Press MENU•PROG to select the Controls menu and highlight Sleep Timer. This menu is yellow.
- B. Press MOVE E to enter the amount of time you want to watch TV before it shuts off. Each press equals 15 minutes.
- C. Press MOVE F to subtract time from the sleep timer.




2. Add more time



- A. When 0:01 appears on the screen, the TV will shut off in one minute. Press MOVE E to add more time.

3. Cancel the Timer




- A. Press MENU•PROG to select the Controls menu and highlight Sleep Timer.
- B. Press MOVE F until the time reaches -- : --.

Using Advanced Features

Setting the Alarm Clock


The TV can be set to turn on each day like your alarm clock. You can set it to turn on to your favorite channel at a certain time. You can also set it to turn itself off again. The Alarm cannot be used until the clock is set.

1. Turn on the Alarm




- A. Press MENU•PROG to select the Alarm menu and highlight Alarm. This menu is green.
- B. Press MOVE E or F to select On or Off.

2. Set the Alarm Channel




- A. Press MOVE H (down) to highlight the Alarm Channel.
- B. Press MOVE E to highlight the channel number.
- C. Enter the channel that you want the TV to turn on to with the number buttons.

3. Set On and Off Times



- A. Press MOVE H (down) to highlight the On or Off Time.
- B. Press MOVE F to set the hour.
- C. Press MOVE E to set the minutes.
- D. Press and hold MOVE F to choose Disabled. This turns the TV only on or only off at a certain time each day.



Using Advanced Features

Selecting a Language

The on-screen displays in this TV can be displayed in three languages: English, French, and Spanish. When you select a language, most of the displays will be shown on the screen in your preferred language.

1. Select the Setup menu

2. Select Language



Press MENU repeatedly to select the Setup menu. This menu is white.

Press MOVE F or E to select English, Français (French), or Español (Spanish).


Using Advanced Features

Watching Closed Captioning

Closed captioning displays the audio portion of a program as words on the TV screen. It is useful for the deaf, hearing impaired, or anyone who wants to watch a program without sound. If you have turned Closed Captioning on and it does not appear on the screen, it is not available on the channel you are watching. This TV does not support the text mode. Text information typically consists of program information, weather bulletins, local activities, etc.

1. Select the Controls Menu


2. Highlight Closed Captioning



Press MENU•PROG to select the Controls menu. This menu is yellow.

Press MOVE H (down) to highlight Closed Captioning.

3. Select Setting



Press MOVE F or E to select Off, CC1, or CC2. Select CC1 for full translation of the primary language in your area. Select CC2 for secondary language translation, simplified English, or whatever is being broadcast in your area.

Using Advanced Features

Setting Your TV for Antenna or Cable

Your TV automatically adjusts this feature when the TV places channels in memory (autoprogram). Follow the steps below to change the setting as needed.

1. Select the Setup menu



Press MENU•PROG repeatedly to select the Setup menu. This menu is white.

2. Highlight Cable/Air



Press MOVE H (down) to highlight Cable / Air.

3. Select Cable or Air




Press MOVE F or E to select Cable or Air. Select Cable if you have cable. Select Air if you have a home antenna connected to your TV.

References

Front Panel Buttons

For details on using buttons with menus, see Menu Basics on page 5.



MENU

Shows menus on screen.
Moves from menu to menu.

CH 2 and 1

Channel up and down.
Scans up and down through channels in the TV's memory.
Moves up and down menus.

VOL + and – (Also VOL 2 and VOL 1)

Volume up and down
Raises and lowers sound.
Moves left and right on a menu line.
Changes a features setting.


POWER

Turns the TV on or off.

References

Displays on the Screen

Your TV shows the settings of several features on the screen. To see what features have been set on your TV, press DISPLAY on the remote.



Screen Display

12:00 AM

XETU

13

Video 00

Alarm

Sleep

Volume

Unusable Signal

Mute

Stereo

Stereo*

SAP

1:55

Description

Time of the clock. *Details are on page 3.*

Name you chose to describe the channel. *Details are on page 22.*

Channel number you are watching.

Indicates that a component is connected to the VIDEO jack on the back of the TV, it is turned on, and channel 00 is selected.

Alarm clock is set to turn on or off. *Details are on page 24.*

Sleep Timer is set to turn off the TV. *Details are on page 23.*

Sound level of the TV.

No signal is coming in on video input channel 00.

There is no sound. *See MUTE button on page 6.*

The sound is being broadcast in stereo. *Details are on page 18.*

SAP is selected in the menu, but it is not available for the program being broadcast. *Details are on page 18.*

Secondary Audio Program. SAP is selected and it is available for the program being broadcast. *Details are on page 18.*

The time remaining for commercial skip. *Details are on page 6.*

References

Trouble Checks

You may have problems that can be fixed with a few minor adjustments. Look for the type of problem you are having below and then try the suggestions to get your TV going again.

Trouble	Checks and Adjustments
<u>Power</u>	
TV will not turn on	Plug TV in. Plug something else into the outlet to make sure it is working. Make sure batteries in the remote are not dead. Aim the remote at the TV and press TV. Make sure batteries are placed in the remote the right way. <i>See batteries on page 2.</i> Unplug TV for a few minutes and then turn it on again.
No picture, no sound but TV has power	Check antenna connections. Check position of Cable / Air feature. <i>See page 27.</i> Try another channel. Inactive channel may be tuned. Make sure component connected to the VIDEO INPUT jacks is turned on if you choose channel 00. Make sure TV is tuned to the same channel as the switch on back of VCR if watching a VCR. Make sure TV / VCR button on VCR is in correct position when using VCR.
<u>Picture</u>	
Blank screen or Unusable Signal appears on screen	Try another channel. Scan the channels.
Picture poor, sound okay	Check antenna connections. Adjust TV picture. <i>See pages 16–17.</i>
<u>Sound</u>	
Noisy stereo reception	Turn Stereo off. The stereo broadcast may not be clear. <i>See page 18.</i>
Picture okay, no sound	Press VOLUME + or MUTE to restore sound. Make sure TV's speakers are on. <i>Details are on page 19.</i>
Picture okay, sound poor	Try another channel. Try adjusting the Tone. <i>See page 18.</i> Change Stereo to off. The stereo broadcast may not be clear. <i>See page 18.</i>
No stereo on stereo station	Make sure Stereo is turned on. <i>See page 18.</i>

References

Trouble Checks

Trouble

Checks and Adjustments

Remote

Buttons don't work when you press them

Press TV to set the remote to control the TV. *See buttons on page 6-7.*

Works part or none of the time

Clear the path between the remote and TV of any objects.
Aim the remote at the component you are trying to control.
Press TV so remote will control TV.
Make sure batteries in the remote are not dead.
See if batteries are placed in remote correctly. *See batteries, page 2.*

Can't select certain channel

Press number buttons. Channel may not be in memory. *See autoprogram on page 20.*
Make sure TV/VCR switch on VCR is in the TV position.
For numbers over 100, press and hold 1 until 1-- appears, then press the other two numbers.
Set Cable/ Air feature to Cable for channels higher than 69. *See page 27.*

TV Turns on or off

Turns off by itself

Check Sleep Timer. *See sleep timer on page 23.*
Wait 30 seconds and turn on again, a power surge may have occurred.
Check Alarm Off time. *See alarm clock on page 24.*

Turns on by itself

Check Alarm On Time. *See alarm clock on page 24.*
Check clock time. *See clock on page 3.*

Does not turn off at Alarm Time

Make sure alarm is turned on or off. *See alarm clock on page 24.*
Check clock time. *See clock on page 3.*

Cleaning Your TV

To clean your TV cabinet, we recommend Murphy's® Oil Soap or Cleaner #AH035. You **should not** use cleaners such as Windex® with vinegar, Lenox® Furniture Polish spray or Heinz® Cleaning Vinegar to clean your TV cabinet. Using these cleaners will permanently mar the surface of the cabinet.

References

Index

A

Adding Channels to Memory 20
 Adjust Menu
 Autocolor 17
 Bright.....17
 Color.....17
 Picture Reset.....17
 Sharpness.....17
 Tint.....17
 Adjusting
 Picture 16
 Picture Settings 17
 Sound Settings 18,19
 Air or Cable Feature.....27
 Alarm Channel.....24
 Alarm Clock 24
 Alarm Display.....28
 Alarm Menu 24
 Alarm 24
 Alarm Channel.....24
 Off Time 24
 On Time 24
 Set Clock 3
 ANT A • B Button 7
 Antenna 27
 Audio 7,15,18,19
 AUDIO Button 7,15
 Audio Codes 15
 Audio Equipment Buttons 15
 CLEAR
 FF / Fast Forward
 PAUSE
 PLAY
 REC / Record
 REW / Rewind
 STOP
 Autocolor 17
 Autoprogram 3,20

B

Batteries (Remote) 2
 Bright 17
 Brightness 17
 Buttons
 + and - 2,3,4,5,6,7
 Audio Equipment.....15
 Component.....4
 Laserdisc.....14
 Menu 4,5
 Number 6
 Power 6
 Remote Control.....4,6,7
 TV 4,12
 TV Front Panel 28
 VCR 13

C

CABLE / ANTENNA Jack 15
 Cable Box 12,13
 Cable Box Codes 12
 CABLE Button.....7,12,13
 Cable Channel.....13
 Cable or Air Feature.....27
 Cancelling Sleep Timer.....23
 Captioning, Closed.....26
 Cautions.....i
 Channel Label 22
 Channel Memory.....3,20,21
 Channel Name Display 29
 Channel Number Display 29
 CHANNEL Up / Down Buttons
 Remote 4,5,6
 TV 28
 Channels
 Adding 21
 Deleting.....21
 Naming 22,29
 Placing in Memory 3,20,21
 Checks and Adjustments.....30,31
 CLEAR Button 6,7
 Clock.....3,24
 Closed Captioning.....26
 Codes
 Audio 15
 Cable Box.....12
 Laserdisc Player.....14
 VCR 8
 Color 17
 Colors (Menus) 5
 Commerical Skip 6,29
 Button 6
 Display 29
 Component.....35
 Component Buttons 13
 AUDIO, CABLE, LD,
 VCR, VCR2, Components
 Audio Equipment.....15
 Cable Box.....12,13
 Laserdisc Player.....14
 VCR 8,9,10,11
 Contents.....1
 Controls
 TV Front Panel 28
 Remote 6,7
 Controls Menu
 Closed Captioning.....26
 Picture 16
 Sleep Timer.....23
 Stereo.....18
 Tone 18

D

Delete Channels from Memory .20
 DISPLAY Button.....6,29

Displays (On-Screen) 29
 Alarm, Channel Name,
 Channel Number, Commerical
 Skip, Mute, Sleep, Stereo,
 Time, Unusable Signal,
 VIDEO 00, Volume

E

Erase a Name 22
 Erase Channels from Memory...20

F

FF / Fast Forward Button 7
 Front Panel Controls 4,28

G

Guide
 Colors 5
 Menu Buttons.....4,5
 Moving through the Menus.....5
 TV 2,3,4,5

H

Hook up TV....Connections Guide

I

INPUT Button 7

L

Laserdisc Player Codes.....14
 Laserdisc Player Buttons 7,14
 FF / Fast Forward, PAUSE, PLAY,
 PROG / Program, REW / Rewind,
 STOP
 Laserdisc Player.....14

M

MENU Buttons 4,5
 Menus.....5
 Menu Colors.....5
 Mono 18
 MOVE Button.....2,5,7
 Moving through the Menus.....5
 MUTE Button 6
 Mute Display.....29

N

Naming the Channels 22
 Number Buttons 6

O	
Off Time (Alarm).....	24
On-Screen Displays.....	29
On Time (Alarm)	24

P	
PAUSE Button.....	7,8,14
Picture	16,17
Picture Adjustments.....	16,17
Picture Settings	16,17
Picture Reset.....	17
Place Channels in Memory	3,20,21
PLAY Button	7,8,14,15
Plug in TV.....	2
POWER Button	2,6
Power Buttons.....	2,6
PREV CH Button	6
Previous Channel Button	6
Problem Solving	31,32
PROG / Program Button.....	7
Programming the Remote	
Audio Equipment.....	15
Cable Box	12,13
Laserdisc Player.....	14
VCR	8,9,10,11
Put Batteries in Remote	2

Q	
Quick Guide to Your TV	2,3,4,5

R	
REC / Record Button.....	7,11,15
References	28-33
Trouble Checks	30,31
Remote Control	
Batteries	2
Buttons	6,7
Tour	4
With Components	7,8-15
RESET Button.....	6
REW / Rewind Button	7,8,11,14,15

S	
Safety Information	i
Screen Displays.....	29
Set Clock	3
Set Time	3
Setting Cable / Air	27
Setting the Cable Channel.....	12
Setting the Sleep Timer.....	23
Setup Menu	
Autoprogram	3,20
Cable / Air	27
Cable Channel.....	13
Channel Label	22

Channel Memory.....	3,20,21
Speakers	9
VCR 1 Channel.....	8
Sharpness.....	17
SKIP	6
Sleep Display.....	23,29
Sleep Timer.....	23
Sharpness.....	17
Sound	18,19
Speakers	19
Startup.....	2,3
Stereo.....	18
Stereo Display	29
STOP Button.....	7,8,11,15

T	
Table of Contents.....	1
Time	
Alarm	24
Clock.....	3
Sleep Timer.....	23
Time Display	29
Tint.....	17
Tone	18
Tour of the Remote.....	4
Trouble Checks	30,31
Turn on Alarm	24
Turn on TV	2
TV	
Buttons	4,6,28
Guide to	2,3,4
TV Button	3,4,6
Time.....	3

U	
Unusable Signal Display	29
Using Advanced Features.....	20-27
Add / Delete channels.....	21
Naming the Channels	22
Place Channels in Memory	20
Setting Cable or Air.....	27
Setting the Alarm Clock	24
Setting the Sleep Timer.....	23
Watching Closed Captioning..	26
Using the Remote	
Audio Equipment.....	15
Laserdisc Player.....	14
Cable Box	12,13
VCR	8,9,10,11

V	
VCR	
Turn on.....	10
Turn off	10
Record one TV program and	
watch another	11
Watch a tape.....	11
VCR Button	7,8,9,10
VCR 1 Channel.....	8
VCR2 Button	7,8,9,10
VCR Codes	8
VCR Buttons.....	7,8
CLEAR, FF / Fast Forward,	
PAUSE, PLAY, PROG / Program,	
REC / Record, REW / Rewind,	
STOP	
VIDEO 00 Display	29
Volume Display	29
VOL + and – Buttons	
Remote	4,6
TV	28

W	
Warning	i
Watching Closed Captioning.....	26

EXPORTED BY:

Thomson Consumer Electronics, Inc.
600 North Sherman Drive
Indianapolis, IN 46201-1976

COUNTRY OF ORIGIN:

M21500 - CANADA
M27500 - U.S.A.

©1994 Thomson Consumer Electronics, Inc.
Trademark(s)® Registered
Marca(s) Registrada(s)
Printed in the U.S.A.
Part Number 1Q57 550-S1C

Other ManualsLib Projects

 www.manualslib.com

 www.manualslib.de

 www.manualslib.es

 www.manualslib.fr

 www.manualslib.nl

 www.manualslib.mx

 www.manualslib.tech 30+ Languages